



$\tau_{mc}$  = Mohr-Coulomb failure strength  
 $\tau_0$  = cohesive strength  
 $\tau_f$  = failure stress  
 $\sigma_n$  = normal stress

$\eta$  = coefficient of internal friction  
 $\phi$  = angle of internal friction